


FADER KNOBS



Penny & Giles PG11

- 58-030 PENNY AND GILES PG11 FADER KNOB 11mm wide, for 18.6x1.7mm arm, black
- 58-032 PENNY AND GILES PG11 FADER KNOB 11mm wide, for 18.6x1.7mm arm, red
- 58-033 PENNY AND GILES PG11 FADER KNOB 11mm wide, for 18.6x1.7mm arm, orange
- 58-034 PENNY AND GILES PG11 FADER KNOB 11mm wide, for 18.6x1.7mm arm, yellow
- 58-035 PENNY AND GILES PG11 FADER KNOB 11mm wide, for 18.6x1.7mm arm, green
- 58-036 PENNY AND GILES PG11 FADER KNOB 11mm wide, for 18.6x1.7mm arm, blue
- 58-038 PENNY AND GILES PG11 FADER KNOB 11mm wide, for 18.6x1.7mm arm, grey
- 58-039 PENNY AND GILES PG11 FADER KNOB 11mm wide, for 18.6x1.7mm arm, white

Width of Fader knob	11mm
Accommodates Fader Stub/Arms	18.6 × 1.7mm
Depth of slot	4mm

Penny & Giles PG16

- 58-040 PENNY AND GILES PG16 FADER KNOB 16mm wide, for 18.6x1.7mm arm, black
- 58-042 PENNY AND GILES PG16 FADER KNOB 16mm wide, for 18.6x1.7mm arm, red
- 58-043 PENNY AND GILES PG16 FADER KNOB 16mm wide, for 18.6x1.7mm arm, orange
- 58-044 PENNY AND GILES PG16 FADER KNOB 16mm wide, for 18.6x1.7mm arm, yellow
- 58-045 PENNY AND GILES PG16 FADER KNOB 16mm wide, for 18.6x1.7mm arm, green
- 58-046 PENNY AND GILES PG16 FADER KNOB 16mm wide, for 18.6x1.7mm arm, blue
- 58-048 PENNY AND GILES PG16 FADER KNOB 16mm wide, for 18.6x1.7mm arm, grey
- 58-049 PENNY AND GILES PG16 FADER KNOB 16mm wide, for 18.6x1.7mm arm, white

Width of Fader knob	11mm
Accommodates Fader Stub/Arms	18.6 × 1.2mm or 9.8 × 1.7mm.
Depth of slot	4mm